



Microelectronic flush diaphragm gauge pressure sensors PF Series

- ▶ Resolution 0,01 %
- ▶ Operating pressure range
from 0-1 to 0-40 MPa
- ▶ Operating temperature range
from -40 to +200 °C
- ▶ Electrical insulation
strength – 500 V
- ▶ Titanium body



Applications

- Industrial automatics
- Pumping stations/ Compressors
- Heat metering

- The sensors are intended for proportional conversion of pressure into electric signal.

New solutions in pressure measurement – “Silicon-on-Sapphire” Technology

∨ Sensitive element of pressure sensors is a two-layer sapphire-titanium diaphragm with monocrystal silicon resistance strain gauges.

∨ Monocrystal sapphire diaphragm is a perfect elastic element that due to connection with titanium acquires the best quality as to the deformation level, and preserves its elastic properties up to +400°C.

∨ Monocrystal silicon resistance strain gauges are automatically connected with sapphire (heteroepitaxy method) and provide almost no hysteresis or fatigue effects.

∨ Exceptional insulating properties and radiation resistance of sapphire enable to use the sensitive element within temperature range from -200 to +350°C under the effect of high electromagnetic interferences and radiation.

∨ Strain gauges elements are manufactured in groups by solid-state micro-electronic methods and provide high quality and good repeatability of the output parameters.

Microtensor

Flush diaphragm pressure sensors PF Series

Datasheet

1 Nominal, overload and burst pressure

Designation	Nominal pressure, MPa	Overload pressure, MPa	Burst pressure, MPa
PF 1...	0...1	-0,1...2	3
PF 1,6...	0...1,6	-0,1...3,2	4,8
PF 2,5...	0...2,5	-0,1...5	7,5
PF 4...	0...4	-0,1...8	12
PF 6...	0...6	-0,1...12	18
PF 10...	0...10	-0,1...20	30
PF 16...	0...16	-0,1...32	48
PF 25...	0...25	-0,1...50	75
PF 40...	0...40	-0,1...60	80

2 Temperature ranges

2.1 Operating temperature range

- 2.1.1 Version 1 from - 40 to + 125°C
- 2.1.2 Version 2 from - 20 to + 155°C
- 2.1.3 Version 3 from - 20 to + 200°C

2.2 Limiting temperature range

- 2.2.1 Version 1 from - 40 to + 130°C
- 2.2.2 Version 2 from - 20 to + 160°C
- 2.2.3 Version 3 from - 20 to + 200°C

Microtensor

Flush diaphragm pressure sensors PF Series

3 Accuracy parameters

3.1 Resolution, % FS	0,01
3.2 Non-linearity, % FS	±0,2
3.3 Variation, % FS	0,1
3.4 Output signal repeatability, % FS	±0,15
3.5 Long-term stability of the output signal range within 12 months, %	±0,2
3.6 Output signal error caused by the influence of overload pressures, % FS	
for zero output signal	±0,2
for output signal range	±0,05
3.7 Additional ambient temperature error, % FS/1°C	
3.7.1 Zero output signal	0,05±0,07
3.7.2 Output signal range	
operating temperature range from -40 to +125 °C	±0,05
operating temperature range from +125 to +200 °C	-0,05±0,025
3.8 Additional vibration error of the output signal, % FS	±0,05

4 Electrical characteristics

4.1 Output signal at room temperature, mV	
4.1.1 Zero output signal	±20
4.1.2 Output signal range (FS)	150±50
for PF 1...	100±35
4.2 Strain gauge bridge resistance at room temperature, kOhm	3,40-4,85
4.3 Temperature resistance coefficient of the strain gauge bridge, K ⁻¹	
4.3.1 Modification V	(1,75±0,1)·10 ⁻³
4.3.2 Modification C	(1,2±0,2)·10 ⁻³
4.4 Insulation resistance, MOhm	
at room temperature	100
at the upper ambient temperature value	20
4.5 Electrical insulation strength (AC voltage), V	500
4.6 Power supply	
4.6.1 Modification V - stabilized DC voltage, V	1-10
4.6.2 Modification C - stabilized DC, mA	0,2-2

Output signal is rated by the voltage 10 V and by the current 1,5 mA.

5 Mechanical characteristics

5.1 Vibration resistance (sinusoidal vibration):

Frequency range, Hzfrom 10 to 2000

Acceleration amplitude, m/s^2 100

5.2 Shock resistance (multiple mechanical shocks):

Shock acceleration peak, m/s^2 500

Shock pulse width, ms 2-5

6 Operating conditions

6.1 IP level IP40

6.2 Sensor body (pressure connection) and diaphragm are made of titanium alloy with 87 % of titanium.

6.3 Pressure media - gases, liquids and their mixtures not aggressive to the titanium alloy (air, sea water, 5 % vitriol acid , chlorine water, chloride solutions, oils etc)


Microtensor

Flush diaphragm pressure sensors PF Series

7 Overall and mounting dimensions

7.1 Pressure sensors of version 1

PF 1(1,6...10)-101(111, 201, 211, 301, 311)-...-K1




Drawing 1

Thread	Code
1/2-14 NPT	K1

7.2 Pressure sensors of version 2


PF 1(1,6...10)-102(112, 202, 212, 302, 312)-...-K1



The rest -
ref. drawing 1
Drawing 2

Thread design


PF 1(1,6...10)-101(111, 201, 211, 301, 311, 102, 112, 202, 212, 302, 312)-...-M1(G1)



Thread	Code
M20x1,5-8g	M1
G1/2-A	G1

7.3 Pressure sensors of version 3

PF 16(25; 40)-103(113, 203, 213, 303, 313)-...-M2(U1)



Thread	Code
M14x1,5-8g	M2
9/16-18UNF-2A	U1

Drawing 3


Microtensor

Flush diaphragm pressure sensors PF Series


8 Circuit diagram

Electrical connection - flexible wire with section 0,08 or 0,12 mm²
in teflon insulation

"Closed bridge" diagram




"Open bridge" diagram




9 Mounting diagrams


PF 1(1,6...10)-101(111, 201, 211, 301, 311, 102
112, 202, 212, 302, 312)-...-M1



PF 16(25, 40)-103(113, 203, 213, 303, 313)-...-M2(U1)



PF 1(1,6...10)-101(111, 201, 211, 301, 311, 102
112, 202, 212, 302, 312)-...-G1



Microtensor

Flush diaphragm pressure sensors PF Series

10 Type designation

PF XX - XXX - X - XX

Series

Upper gauge pressure limit

1; 1,6; 2,5; 4; 6; 10; 16; 25; 40 MPa

Operating ambient temperature range

Version 1 - from - 40 to + 125 °C;

Version 2 - from - 20 to + 155 °C;

Version 3 - from - 20 to + 200 °C

Circuit

0 - “closed bridge” circuit;

1 - “open bridge” circuit

Version

1 - with 27 hex and thread M24x0,75 (drawing 1);

2 - with 27 hex and thread M22x1 (drawing 2);

3 - with 22 hex and thread M20x1 (drawing 3)

Power supply modification

V - stabilized DC voltage (1-10 V);

C - stabilized DC (0,2-2 mA)

Thread code

K1 - 1/2-14 NPT (drawings 1, 2);

M2 - M14x1,5-8g (drawing 3);

M1 - M20x1,5-8g (drawings 1, 2);

U1 - 9/16-18UNF-2A (drawing 3)

G1 - G1/2-A (drawings 1, 2);

Order example of pressure sensor

Pressure sensor of PF series, intended for pressure conversion from 0 to 2,5 MPa, for operation within temperature range from - 40 to + 125 °C, with “closed bridge” circuit, with 27 hex and thread M24x0,75, DC voltage power supply, M20x1,5-8g thread:

Pressure sensor PF 2,5-101-V-M1.

Note: if wished, the wire length (standard 80 mm) can be changed, in this case the required length should be added to the wire code L, for example:

Pressure sensor PF 2,5-101-V-M1-L120.

11 Marking

Marking on the sensor body must contain following information: series, upper gauge pressure limit in MPa, version of the operating temperature range, circuit type, version of design, power supply modification, thread code and order number.

Microtensor

Flush diaphragm pressure sensors PF Series